

## HSM-Schwickert

Eichendorffweg 29 ,71032 Böblingen  
Tel. 07031/222743 Fax 07031/222884  
e-mail: mail@hsm-schwickert.de



## **Operating instructions HSM-MEGA-FLIP „Safe-view“ system**

Take a few minutes now to read these brief instructions. This HSM system has been designed to give you seasons of no-hassle safe viewing. Understand how your MEGA-FLIP functions to ensure trouble-free operation.

### **Mounting shield**

Snap face guard into place on peak and hold unit in position on helmet while your mark is outline. Be sure lower edge of face guard overlaps helmet opening. Remove protective paper from sticky adhesive. Affix entire unit to helmet. Hold in place with rubber straps supplied.

### **Attaching sheets**

Locate track guides on visor. Sheets with „loop automatic“ will be inserted here. Cut loop off first sheet so that it can not be pulled off. This protects visor behind it. Then, insert any number of sheets. Fold over each loop. Then press next sheet over it. The last loop must be on top. This way, only one sheet at a time will be ripped off. Following loop will always come into position ready for rip off. Fasten sheets on right side of helmet. To do this, bend back right side shield to clamp sheets in place. Run out of new sheets while riding? Simply flip visor out of way.

### **Only original HSM films sheets will assure trouble-free operation.**

Your HSM „safe-view“ system was designed to optimise vision.  
The MEGA-FLIP is not a substitute for goggles.

Always wear approved eye protection when your ride!